OMNITOUCH 7[™] TABLE TOP STAND

Cat. No. 99A16



PK-A3106-10-00-0A

INSTALLATION ENGLISH

WARNINGS AND CAUTIONS

- WARNING: TO AVOID DEATH OR SERIOUS PERSONAL INJURY never push objects of any kind into this product through openings, as they may touch dangerous voltages.
- WARNING: TO AVOID DEATH OR SERIOUS PERSONAL INJURY never touch uninsulated wires or terminals unless the wiring has been disconnected at the network interface.
- Read and understand all instructions. Follow all warnings and instructions marked on the product.

Description

The Leviton® 99A16 Table Top Stand is used to mount an *OmniTouch 7* Touchscreen for table top applications. It is ideal for board rooms, conference areas, as well as home theaters, and bedside tables.

Included in kit

- 1 Table top stand
- 4 Hook-and-Loop fasteners (for securing the *OmniTouch 7* to the stand)
- 4 Rubber feet (for shock absorption and a skid-free application)

Installation

- Remove the plastic cover from one of the rubber feet, exposing the adhesive.
- Press and firmly hold the rubber foot to one of the four mounting locations on the bottom of the stand, for approximately 5 seconds to insure a secure attachment. Refer to *Figure 1* for recommended mounting locations.
- 3. Repeat Steps 1 and 2 for the remaining 3 rubber feet.
- 4. Separate the 4 "Hook-and-Loop" fasteners from each other.
- Remove the plastic covers from one of the "Hook" fasteners, exposing the adhesive backs.
- 6. Press and firmly hold the "Hook" fasteners combination to one of the four mounting locations on the front of the stand, for approximately 5 seconds to insure a secure attachment. Refer to *Figure 2* for recommended mounting locations.
- 7. Repeat Steps 5 and 6 for the remaining 3 "Hook" fasteners.
- Lightly press each of the "Loop" fasteners back onto the respective "Hook" fasteners.
- 9. Remove the plastic covers from the 4 exposed "Loop" fasteners.
- 10. Place the OmniTouch 7 into the stand, allowing the back of the OmniTouch 7 to make contact with the adhesive on the "Loop" fasteners. Press and hold firmly for approximately 5 seconds.

WARNINGS AND CAUTIONS

- **Do not use this product near water** e.g., near a tub, wash basin, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
- Never install communications wiring or components during a lightning storm.
- Never install communications components in wet locations unless the components are designed specifically for use in wet locations.
- Use caution when installing or modifying communications wiring or components.
- SAVE THESE INSTRUCTIONS.

Figure 1 Bottom





Figure 2



COPYRIGHT AND TRADEMARK INFORMATION

This document and all its contents herein are subject to and protected by international copyright and other intellectual property rights and are the property of Leviton Manufacturing Co., Inc, its subsidiaries, affiliates and/or licensors. Use herein of third party trademarks, service marks, trade names, brand names and/or product names are for informational purposes only, are/may be the trademarks of their respective owners; such use is not meant to imply affiliation, sponsorship, or endorsement. No part of this document may be reproduced, transmitted or transcribed without the express written permission of Leviton Manufacturing Co.. Inc.

FOR CANADA ONLY

For warranty information and/or product returns, residents of Canada should contact Leviton in writing at Leviton Manufacturing of Canada Ltd to the attention of the Quality Assurance Department, 165 Hymus Blvd, Pointe-Claire (Quebec), Canada H9R 1E9 or by telephone at 1 800 405-5320.

LEVITON LIMITED WARRANTY

Leviton warrants to the original consumer purchaser and not for the benefit of anyone else that products manufactured by Leviton under the Leviton brand name ("Product") will be free from defects in material and workmanship for the time periods indicated below, whichever is shorter: • OmniPro II and Lumina Pro: three (3) years from installation or 42 months from manufacture date. • Omni LTe, Omni IIe, and Lumina: two (2) years from installation or 30 months from manufacture date. • BitWise Controllers: two (2) years from installation or 30 months from manufacture date. • Batteries: Rechargeable batteries in products are warranted for ninety (90) days from date of purchase. Note: Primary (non-rechargeable) batteries shipped in products are not warranted. Products with Windows* Operating Systems: During the warranty period, Leviton will restore corrupted operating systems to factory default at no charge, provided that the product has been used as originally intended. Installation of non-Leviton software or modification of the operating system voids this warranty. Leviton's obligation under this Limited Warranty with new or remanufactured product. Leviton will not be responsible for labor costs of removal or reinstallation of Product. The repaired or replaced product is then warranted under the terms of this Limited Warranty for the remainder of the Limited Warranty time period or ninety (90) days, whichever is longer. This Limited Warranty does not cover PC-based software products. Leviton is not responsible for conditions or applications beyond Leviton's control. Leviton is not responsible for sesues related to improper installation, including failure to follow written Installation and operation instructions, normal wear and tear, catastrophe, fault or negligence of the user or other problems external to the Product. To view complete warranty and instructions for returning product, please visit us at www.leviton.com. negligence of the user or other problems external to the Product. To view complete warranty and instructions for returning product, please visit us at www.leviton.com.