


Decora Smart® 4-Button Controller with Wi-Fi® Technology

decora smart



APPLICATION

The Decora Smart Wi-Fi 4-Button Controller (DW4BC) provides sophisticated in-wall control of multiple Decora Smart Wi-Fi devices, room lighting scenes and whole house lighting activities. Use with Decora Smart Wi-Fi lighting controls and the My Leviton app to offer an “always there, always on” control center for smart lighting. Adjust devices, activate scenes in a room, or push one button to turn on or off every Decora Smart Wi-Fi light in the home.

The DW4BC requires hot, neutral, and ground wires, and does not directly connect to a load. The four buttons can be customized for control via the My Leviton app.


WORKS WITH MY LEVITON

Simply use the My Leviton app to enroll all of your Leviton smart devices, then use the app to assign specific functions to each of

the 4 buttons on the face of the device. For instance, the top button could be “All On”, the 4th button could be “All Off” and then 3 and 4 could be commonly used scenes such as “Dinner Time” and “Party Mode”. The custom lighting scenes can include any product from the Decora Smart Wi-Fi family including dimmers, switches and smart plugs.

CUSTOM ENGRAVED BUTTONS

Take it to the next level by ordering custom engraved buttons for your 4-Button Controller. These can be designed and ordered at any time through the My Leviton app. The buttons are available in six color options. Custom Engraved Buttons are currently available to U.S. customers only.



Leviton Manufacturing Co., Inc. Global Headquarters

201 N. Service Rd., Melville, NY 11747-3138 Tech Line: 1-800-824-3005 Fax: 1-800-832-9538

Visit our Website at: www.leviton.com/decorasmartwifi

©2021 Leviton Manufacturing Co., Inc. All rights reserved. Subject to change without notice.

PRODUCT DATA**FEATURES**

- To be installed in locations with hot, neutral and ground wires present. An electrical load cannot be directly wired to this product
- Use the My Leviton app to create scenes and lighting activities
- Buttons feature feedback lights that illuminate upon button press, then vanish
- Up to 8 DW4BC's may be used per Residence
- Engraved buttons available in all 6 color options can be designed and ordered at any time through the My Leviton app (U.S. only)

BENEFITS

- Control room or house scenes from a button
- In retrofit applications, may be installed in a multi-way circuit along with a Decora Smart Wi-Fi switch or dimmer
- Enact All Off, Movie Time, and more

RATINGS

- No load control


- 120VAC, 50/60Hz

RATINGS AND CERTIFICATIONS

- cULus Listed, Energy Mgmt Equip. 9D34
- NOM (Mexico)
- Wi-Fi CERTIFIED™
- Complies with FCC Part 15, Class B
- Contains FCC ID: VPY-LB1GC
- Contains IC:772C-LB1GC

WARRANTY INFORMATION

Five-Year Limited Warranty

WIRING DIAGRAM**ORDERING INFORMATION**

DESCRIPTION	CAT. NO.
Decora Smart 4-Button Controller with Wi-Fi Technology	DW4BC-1BW
Decora Smart 4-Button Controller Color Change Kit – White	DS4KT-1PW
Decora Smart 4-Button Controller Color Change Kit – Light Almond	DS4KT-1PT
Decora Smart 4-Button Controller Color Change Kit – Ivory	DS4KT-1PI
Decora Smart 4-Button Controller Color Change Kit –Black	DS4KT-1PE
Decora Smart 4-Button Controller Color Change Kit – Brown	DS4KT-1PB
Decora Smart 4-Button Controller Color Change Kit – Gray	DS4KT-1PG

Leviton Manufacturing Co., Inc. Global Headquarters

201 N. Service Rd., Melville, NY 11747-3138 Tech Line: 1-800-824-3005 Fax: 1-800-832-9538

Visit our Website at: www.leviton.com/decorasmartwifi

©2021 Leviton Manufacturing Co., Inc. All rights reserved. Subject to change without notice.

SAT-10084
REV JUL 2021